











ASSEMBLY INSTRUCTION

DC-30



A		1
B		1
C		3
D		3
E		1
F		1
G		4