





ASSEMBLY INSTRUCTIONS FOR DINING CHAIR
MOD. NO. DC-102





A	B	C	D	E
				
1X	1X	4X	4X	1X